

INSTRUCTIONS FOR APPLYING ADHESIVE DOTS

- 1 BEFORE USING THE DOUBLE FACE ADHESIVE DOTS, MOUNT THE LIGHT WITH SUCTION CUPS FIRST. WITH THE SUCTION CUPS IN PLACE, MAKE A TEMPORARY MARK ON OUTSIDE OF THE WINDOW FOR PROPER LOCATION.**
- 2 REMOVE THE SUCTION CUPS.**
- 3 WIPE HOUSING TABS OR BRACKET TABS AND WINDOW CONTACT AREA WITH ALCOHOL.**
- 4 REMOVE ADHESIVE DOTS FROM THE PAD AND PLACE DOTS ON OUTER TABS OF THE LIGHT HOUSING OR THE OUTER TABS OF THE OUTSIDE BRACKET. PRESS FIRMLY AND HOLD IN PLACE FOR 15 SECONDS.**
- 5 WHEN READY TO MOUNT THE LIGHT ON THE WINDOW, REMOVE THE RED VINYL WITH A SHARP POINTED KNIFE EDGE TO LIFT THE FILM FROM THE OTHER SIDE OF THE ADHESIVE DOTS. PLACE THE LIGHT IN THE PROPER LOCATION ON THE WINDOW AND PRESS THE TABS FIRMLY AND HOLD FOR 15 SECONDS.**
- 6 IF YOU MAKE A MISTAKE AND WANT TO REPOSITION THE LIGHT, YOU STILL CAN REMOVE THE LIGHT FROM THE ADHESIVE AND TRY AGAIN WITH ANOTHER SET OF DOTS. IT WILL TAKE A FEW DAYS TO FULLY CURE THE ADHESIVE BOND.**